




THE HOT SPOT

SILICONE VIBRATING FLEX MASSAGER


Instructions for Use

TO USE:

- Twist and pull the Hot Spot's base to remove the battery cover and insert 4 AAA batteries (not included). Twist to line up arrows and press the base back on to reassemble.



- Press the single-button control on the base to power on and cycle through the different speeds and patterns.
- If desired, apply a **water-based** lubricant to the surface of the Hot Spot before use.
- Press and hold button on base to power off.



WARNING: Do not use with silicone or oil-based lubricants. Remove batteries when not in use. Store in a cool, dry place away from other toys.

Warning for Vibrating Products: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

Safe, sane, and consensual (SSC) is one of the values surrounding ethically acceptable behavior in BDSM, kink, and alternative sexuality communities. Safe means that the risk of activities should be understood by all participants, taking all precautions to prevent accidents or injury. Sane is to undertake activities in a sensible and sane state of mind, understanding the difference between fantasy and reality. Consensual means that all parties have freely and fully consented to the activity and were in a sound state of mind.