

# **Features**



Warming Wand Heats Slowly to Safe Temperature



Deep, Powerful Vibrations



Multi-Function Massager with 7 Vibration Patterns



Luxurious Premium Silicone



USB Rechargeable (Cable Included)

Splashproof

Hypoallergenic, Phthalate-Free, and Body-Safe **DOCJOHNSON** 

ivibe select





### **About This Product**

The iVibe™ Select iWand elevates the classic wand massager from toybox staple to multi-dimensional pleasure tool. In addition to the 7 vibrating and pulsating massage patterns designed to optimally excite, the silicone iWand features a gentle warming effect that slowly heats the silicone wand head to a pleasurable, body-safe temperature. iWand can be used with both the warming and vibrating modes active, or either one.


# Why Silicone?

Silicone is hypoallergenic and nonporous, making it the safest and most high-end material used in today's pleasure products. Our premium silicone is completely body-safe without compromising the beauty of each piece and has a smooth, velvety texture. When we created the iVibe™ Select line of products, we knew that this attractive and hygienic material was the only acceptable choice.

# **Getting Started**

For the best experience, we recommend cleaning and fully charging your iVibe™ Select iWand before the first use.

**To charge**, connect the USB cable included with your iWand into your preferred power source. Locate the small charging port at the bottom of your iWand and firmly push the charger jack into it. (The charging port may appear too small due to iWand's protective silicone exterior, but will stretch to accommodate the charger.)



**LED Flashing:** Charging

LED Continually Lit: Item is fully charged

**LED Off:** Charging Cable Detached

# Using Your iVibe™ Select iWand

iWand can be used with both the vibration and warming modes, or either one independently. Many users find that their iVibe™ experience is improved with the use of a water-based lubricant.

Do not use the iVibe™ Select iWand with oil-based or silicone-based lubes.

#### To Turn On/Off iWand's Powerful Vibrations



<u>Press and hold</u> button for approximately 3 seconds until the LED lights up.

#### To Change the Vibration Pattern



Press button without holding to cycle through patterns until finding the mode you prefer.

#### To Activate iWand's Warming Function



**Turn On:** <u>Press button once without holding.</u> **Turn Off:** <u>Press and hold button until LED is off</u>

### **Care and Maintenance**

Proper cleaning and storage of your iVibe™ Select products are essential for your continued enjoyment.

To clean, spray with Doc Johnson® Toy Cleaner or wash with mild soap and warm water and wipe clean, avoiding iWand's charger port. Do not submerge. Allow your iWand to dry completely before storing separately from other toys in a cool, dry place. (Doc Johnson® Toy Cleaner not included.)

When storing, ensure that your iVibe™ Select product does not come into contact with other toys. Keep away from extreme heat, cold, and moisture. Use iVibe™ Select products with water-based lubricants only: oils and silicone-based lubes will degrade the material of your iWand.

**WARNING FOR VIBRATING PRODUCTS:** To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

Designed by Doc Johnson® in Los Angeles, California. Copyright © 2017 Doc Johnson Enterprises. All Rights Reserved.

For warranty information and product registration, please visit us online at docjohnson.com

