

Features:



DOC JOHNSON™ iVibe™ select iQuiver 7 Piece Set



Instructions

Getting Started:

For the best experience, we recommend cleaning and fully charging your iVibe Select iQuiver before its first use.



To charge, connect the USB cable included with iQuiver into your preferred power source. Locate the small charging port on the base of the iQuiver and firmly push the charger jack into it. The charging port may appear too small due to iQuiver's protective silicone exterior, but it will stretch to accommodate the charger.

Your iQuiver will fully charge in 1 hour for a battery life of 50 minutes. (LED light blinks when charging).



Using your iVibe Select iQuiver:

First, choose which of the 6 included silicone heads to use and twist it until it is securely attached to the base.

To turn on iQuiver's vibrations, press  at the bottom of the toy for approximately 3 seconds until the LED lights up. Press repeatedly, cycling through 10 vibration modes, until you find the feel you prefer. When you are done, hold down  for approximately 3 seconds to turn iQuiver off.

WARNING FOR VIBRATING PRODUCTS: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

CARE INSTRUCTIONS: Silicone head can be cleaned in a variety of ways. Spray with Doc Johnson Toy Cleaner, or wash with mild soap and warm water and wipe clean. Do not submerge. Allow to dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. *Doc Johnson Toy Cleaner sold separately.

