

iRock

iVibe
select



Tip Beckons
Back and Forth
in a "Come
Hither" Motion



Separate Motors for
Custom Control of
Vibrations and
Moving Tip



Multi-Function
Massager with
7 Vibration Patterns



Deep, Powerful
Vibrations



Luxurious
Premium Silicone



Waterproof



USB Rechargeable
(Cable Included)

Hypoallergenic • Phthalate-Free • Body-Safe

To Turn On/Off iRock's
Powerful Vibrations:



Press and hold button
for approximately 3
seconds until the
LED lights up.



LED Lights are located
on both buttons

To Change the
Vibration Pattern:



Press button without
holding to cycle through
patterns until finding the
mode you prefer.

To Activate iRock's
"Come Hither" Function:



Turn On: Press button
once without holding.

Turn Off: Press and hold
button until LED is off.