

DOCJOHNSON

Rimming P-Massager
Vibrating • Rechargeable • Silicone

FIRM, FLEXIBLE PREMIUM SILICONE



Approximate Product Dimensions:

Total Length: 7" (17.78 cm) **Insertable Length:** 5" (12.7 cm) **Width:** 1.25" (3.18 cm) **Circumference:** 4.5" (11.43 cm)

Warning for Vibrating Products: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

For warranty information and product registration, go to **DOCJOHNSON.COM**



DOCJOHNSON.com

OPERATING INSTRUCTIONS

TO OPERATE RIMMING FUNCTION:

- Press and hold to power on rotating ridges.
- Press without holding to cycle through 3 speeds. Double tap to reverse rotation direction
- Press and hold (to power off rotation.



TO OPERATE INSERTABLE SHAFT:

- Press and hold **()** to power on vibration.
- Press without holding to cycle through 10 vibration modes.
- Press and hold **(6)** to power off vibration.



TO OPERATE ADJUSTABLE PERINEUM STIMULATOR:

- Press and hold (to power on vibration.
- Press without holding to cycle through 10 vibration modes.



TO CHARGE:

- Connect USB charger cable to small port on base of product.
- Plug USB Charger cable into any device or charger with a USB port.
- Product fully charges in 2 hours. Usage time is 76 minutes.



CARE INSTRUCTIONS

To clean, spray with Doc Johnson® Toy Cleaner or wash with a mild soap and warm water. Allow to dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide.

*Doc Johnson® Toy Cleaner sold separately.