

Features



Tip Beckons Back and Forth in a "Come Hither" Motion



Separate Motors for Custom Control of Vibrations and Moving Tip



Deep, Powerful Vibrations



Multi-Function Massager with 7 Vibration Patterns



Luxurious Premium Silicone



USB Rechargeable (Cable Included)

Waterproof

Hypoallergenic, Phthalate-Free, and Body-Safe **DOCJOHNSON**







About This Product

The iVibe™ Select iRock elevates the rabbit-style massager from toybox staple to multidimensional pleasure tool. The silicone iRock is an insertable massager with an exterior clitoral stimulator, and a G-spot stimulating shaft that not only vibrates but waves back and forth to rub your pleasure center to perfection. The independently controlled motors of the iVibe™ Select iRock can be used at the same time or separately, with seven exciting vibration patterns.

Why Silicone?

Silicone is hypoallergenic and nonporous, making it the safest and most high-end material used in today's pleasure products. Our premium silicone is completely body-safe without compromising the beauty of each piece and has a smooth, velvety texture. When we created the iVibe™ Select line of products, we knew that this attractive and hygienic material was the only acceptable choice.

Getting Started

For the best experience, we recommend cleaning and fully charging your iVibe™ Select iRock before the first use.

To charge, connect the USB cable included with your iRock into your preferred power source. Locate the small charging port at the bottom of your iRock and firmly push the charger jack into it. (The charging port may appear too small due to iRock's protective silicone exterior, but will stretch to accommodate the charger.)



LED Flashing: Charging

LED Continually Lit: Item is fully charged

LED Off: Charging Cable Detached

Using Your iVibe™ Select iRock

iRock can be used with both or either of the separately-controlled motors enabled, making a number of stimulating combinations possible. Many users find that their iVibe™ experience is improved with the use of a water-based lubricant.

Do not use the iVibe™ Select iRock with oil-based or silicone-based lubes.

To Turn On/Off iRock's Powerful Vibrations



Press and hold button for approximately 3 seconds until the LED lights up.

To Change the Vibration Pattern



Press button without holding to cycle through patterns until finding the mode you prefer.

To Activate iRock's "come hither" Function



Turn On: <u>Press button once without holding</u>.

Turn Off: <u>Press and hold button until LED is off</u>

Care and Maintenance

Proper cleaning and storage of your iVibe™ Select products are essential for your continued enjoyment.

To clean, spray with Doc Johnson® Toy Cleaner or wash with mild soap and warm water and wipe clean, avoiding iRock's charger port. Do not submerge. Allow your iRock to dry completely before storing separately from other toys in a cool, dry place. (Doc Johnson® Toy Cleaner not included.)

When storing, ensure that your iVibe™ Select product does not come into contact with other toys. Keep away from extreme heat, cold, and moisture. Use iVibe™ Select products with water-based lubricants only; oils and silicone-based lubes will degrade the material of your iRock.

WARNING FOR VIBRATING PRODUCTS: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

Designed by Doc Johnson® in Los Angeles, California. Copyright © 2017 Doc Johnson Enterprises. All Rights Reserved.

For warranty information and product registration, please visit us online at docjohnson.com

