



DOCJOHNSON[®]

Wand Vibe in a Bag[™]

Care and Usage Instructions

This black silicone Wand vibrator is a compact version of the classic shape everybody loves. Its strong 10-function motor is quiet for discreet use, and its high-quality hygienic silicone is completely body-safe.

USB rechargeable with the included cable.

To Turn the Vibrations ON: Hold the  for 3 seconds until the Wand begins vibrating. Continue to press  to cycle through 10 vibration patterns.

To Turn the Vibrations OFF: Hold down  on the toy until LED display turns off.

To Charge Wand Vibe: Plug included cable into a USB power source, then locate the charging port on the Vibe and plug in. **Charge time:** 120 Minutes
Usage Time: 50 to 120 Minutes, depending on Usage Speed.

Cleaning and Storage: Spray your Wand with Doc Johnson Toy Cleaner or wash with mild soap and warm water. Allow to air-dry completely before storing separately from other toys in a cool, dry place. Use with water-based lubricant/glide. Doc Johnson Toy Cleaner sold separately.

Warning for Vibrating Products: To avoid injury or aggravation of pre-existing conditions, this product should not be used on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by the use of this product.

For customer service information contact cs@docjohnson.com

For warranty information, go to [docjohnson.com](https://www.docjohnson.com)



PRODUCT USES AND WARNINGS: To ensure the safe use of our products and to extend product life, before using our products please scan the QR code and review our Product Use Guidelines. Although all Doc Johnson products are designed and manufactured with great care, we urge our customers to practice sex toy safety. These Guidelines are also available on our website at <https://www.docjohnson.com/safety-practice>.